

NIKKEI

ACTION CAM

User Manual



MODEL: EXTREME X3

CONTENTS PAGE

Contents Page	1
Introduction	2
Safety Instructions	2
Important Safety Precautions	4
Product Specification	5
Box Contents	6
Getting to know your Action Camera	7
Using the Action Camera	9
Action Camera Operation	11
Connection Via TV/HDTV	22
Using the Mounting Accessories	23
Downloading files to your Computer	29
Troubleshooting	36

INTRODUCTION

Congratulations on the purchase of your new Action Camera. This manual contains important safety and operating information. Please read all the information carefully before you use the device to avoid accidents and keep it for future reference. Follow these important safety and operation instructions.

SAFETY INSTRUCTIONS

- The Action camera shall not be exposed to dripping or splashing and no objects filled with liquids, such as vases, shall be placed over the product. Dry location use only.
- Keep the camera clean. Never store it next to a heat source or in dirty, humid or wet places. Keep it out of direct sunlight.
- Press the screen and buttons gently. Pressing too hard

can damage the product.

- Do not use the camera in an extremely dry environment.
- Do not put the camera in high temperature places (over 40°C), especially not in a car with the windows closed in summer.
- Do not attempt to dismantle or repair this camera yourself. Qualified personnel should perform repairs.
- Disconnect the camera from the power source before cleaning.
- Use a dry soft cloth to clean this camera.
- This product is not intended for commercial use. Household/personal use only.
- Do not disassemble this unit. To prevent the risk of electric shock, do not remove the cover. No user-serviceable parts inside. Refer servicing to qualified personnel.

- The USB cord for the device should be unplugged from the computer when the unit is left unused for a long period of time.
- Do not subject the product to harsh impacts. Do not drop the appliance. This may result in damage to the product.

IMPORTANT SAFETY PRECAUTIONS

In order to prevent program failure, never disconnect the product suddenly from a PC while file transferring is in progress.

Disconnect the appliance from PC when cleaning. Use a dry soft cloth to clean this appliance. Do not dismantle the product or use alcohol, thinners or benzene to clean the surface of the product.

Attention: We have done our best to produce a complete and accurate manual. However, we cannot ensure that there are no errors or omissions during the printing process.

PRODUCT SPECIFICATION

- 5MP CMOS sensor
- Image Resolution: 12M/10M/9M/8M/5M/3M/1M/VGA
- Video Resolution: 1080p/720p/VGA/QVGA
- Wide angle lens
- File Format JPEG, AVI
- 1.77" Preview Screen
- Expandable Micro SD Slot up to 32GB
- High-speed USB 2.0 interface
- Built-in 3.7V rechargeable lithium battery
- Operation Temperature: 0°C to 40°C
- Storage Temperature: -20°C to 45°C
- Works with Windows 7, 8, Vista and XP


BOX CONTENTS

Please make sure that the items shown below are included in the package. Should an item be missing, please contact the local retailer from which you purchased this product.

- | | | |
|----|-----------------------------|---------|
| 1. | Action Camera | 1 piece |
| 2. | Waterproof Case | 1 piece |
| 3. | Bike Mount with Rubber Grip | 1 piece |
| 4. | Helmet Mount with Strap | 1 piece |
| 5. | Helmet Mount Sticker | 1 piece |
| 6. | Mounting Adaptor for GoPro | 1 piece |
| 7. | USB Cable | 1 piece |
| 8. | User Manual | 1 piece |

GETTING TO KNOW YOUR ACTION CAMERA

DEVICE OVERVIEW



1. Power/Shutter

2. Indicator Light



3. Speaker

4. USB Jack

5. Lens

6. Micro SD Slot

7. Microphone



8. LCD Screen

9. Tripod Slot

10. Reset

11. HDMI Jack

12. Mode button

13. Waterproof Case

MINIMUM SYSTEM REQUIREMENTS

Your computer system must meet the following minimum specifications:

Microsoft Windows XP, Vista, 7, 8

Intel Pentium III of more than 800MHz or other CPU with equivalent performance

Larger than 512MB RAM

The sound card and video card shall support DirectX8 or higher version.

Free space of more than 500MB

One standard USB1.1 or USB2.0 port

USING THE ACTION CAMERA

BATTERY OPERATION

1. To charge the internal battery, connect the action camera with the USB cable provided to a computer.

2. The charging indicator will light up red when charging.
3. The battery will become fully charged after 3-4 hours.

Once fully charged the charging indicator will disappear.

INSERTING A MEMORY CARD

This action camera does not have internal memory.

A Micro SD card or multimedia card must be inserted for this action camera to operate. If a card has not been inserted this action camera cannot record.

1. Turn off the action camera.
2. Open the rubber cover at the side of action camera.
3. Find the Micro SD card slot, and then insert the Micro SD card.
4. When the memory card has successfully been inserted, you will be able to start using the action camera.

ACTION CAMERA OPERATION

START-UP/SHUTDOWN

Press the “Shutter/Power” button to turn on the camera, the screen will light up and the camera is on.




Press the “Shutter/Power” button to shut down the device.

When the Action Camera has been idle for 3mins the camera will automatically shut down

Note: The device will shut down when the power of the battery is insufficient. Please charge it in time when the battery is low.

MODE SELECTION

There are three different modes available for this action camera. Press the “Mode” button to switch through each of the below modes,

Display	Title	Description
	Capture mode	For taking still photos.
	Video mode	For recording movie clips.
	Playback mode	For playing recorded files.

ACTION CAMERA SETTINGS

Before taking photos or recording videos, press the “Shutter/Power” button to switch on the action camera first.

Press and hold the “Mode” button and the menu will appear on the LCD screen, and then press the “Shutter/Power” button to access the settings menu as below. Use the “Mode” to select each setting and the “Shutter/Power” buttons to make your selections.


MENU	FUNCTION
Date	This function can be used to add a date to your pictures and video as you take them 【On】 / 【Off】 / 【Set the date】
Auto power off	To save power, the video camera is turned off automatically after a period of time. After you select the "off " that means the power save function is switched off 【1min】 / 【3min】 / 【5min】 / 【Off】
Beep sound	Sets the operation sound : 【On】 / 【Off】

Backlight	<p>Set the backlight (Turns off the screen display while recording) :</p> <p>【1min】 / 【 3min 】 / 【5min】 / 【ON】</p>
Language	<p>Set the on-screen language:</p> <p>【English】 / 【French】 / 【Espanol】 / 【Portuguese】 / 【German】 / 【Dutch】 / 【Italian】</p>
Frequency	<p>Light Frequency should be set depending on your region for Netherlands/Europe setting should be 50Hz:</p> <p>【50HZ】 / 【60HZ】</p>
TV mode	<p>You can review images on TV with the supplied AV cable. TV Out should be set to either NTSC or PAL depending on your region. 【NTSC】 / 【PAL】</p>
Format	<p>Format your SD card including protected</p>

	files, removing the SD card during formatting may damage the card. 【OK】 / 【Cancel】
Default Setting	Restores the action camera to default settings: 【OK】 / 【Cancel】

VIDEO MODE

1. Turn on the action camera, press the “Mode” button until

you reach video mode .

2. Press “Shutter/Power” button to start recording.

3. Press the “Shutter/Power” button again to stop recording.

4. The action camera will stop recording automatically when the memory capacity is full.

NOTE: When recording videos, the action camera will automatically save it in 28minute files. You can record continuously for as long as possible but every 28minutes it will

save a new file and start again.

SETTINGS IN VIDEO MODE


While in video mode, you can change various video settings.

MENU	FUNCTION
Size	Changing the video resolution for the recording. Select small movie size to record longer time. There are four items for option: 【1080p】 / 【720p】 / 【VGA】 / 【QVGA】
Exposure	Set the exposure value manually to compensate for unusual lighting conditions: 【3】 / 【2】 / 【1】 / 【0】 / 【-1】 / 【-2】 / 【-3】
White Balance	Adjust the white balance to suit different light sources. There five items for option: 【Auto】 / 【Daylight】 / 【Cloudy】 / 【Fluorescent】 / 【Incandescent】
Anti-shake	Use the function to avoid your hands shaking

	when taking videos. 【On】 / 【Off】
Motion Detection	When the setting is set to ON the camera will automatically detect any movement within 4 metres and start automatically recording. 【On】 / 【Off】
Record Audio	Record voice when recording movie clips 【On】 / 【Off】
Date Stamp	This function can be used to add a date to your pictures as you take them. There are two items for option: 【On】 / 【Off】

CAPTURE MODE

1. Turn on the action camera, press the “Mode” button until

you reach capture mode .

2. Press “Shutter/Power” button to take photo.
3. After the image has been taken the LCD will display the image for a brief second.
4. The memory capacity in the top right of screen will decrease as each image is taken.

SETTINGS IN CAPTURE MODE

While in capture mode, you can change various video settings.

MENU	FUNCTION
Capture Mode	Using this function to set the camera to different action camera taking modes: 【Single】 / 【2s timer】 / 【5s timer】 / 【10s timer】
Resolution	Allow to change the image resolution for


	<p>taking still photos:</p> <p>【12M】 / 【10M】 / 【9M】 / 【8M】 / 【5M】 / 【3M】 / 【1M】 / 【VGA】</p>
Quality	<p>Select a lower image quality to decrease the image size in order to take more images.</p> <p>There are three options for choice:</p> <p>【Super Fine】 / 【Fine】 / 【 Normal】</p>
Sharpness	<p>You can set the level of sharpness in the images taken with your camera. The sharpness level dictates if the edges of objects in the image are more or less distinct. 【Sharp】 / 【Normal】 / 【Soft】</p>
Exposure	<p>Set the exposure value manually to compensate for unusual lighting conditions:</p> <p>【3】 / 【2】 / 【1】 / 【0】 / 【-1】 / 【-2】 / 【-3】</p>

<p>White balance</p>	<p>Adjust the white balance to suit different light sources. There five items for option:</p> <p>【Auto】 / 【Daylight】 / 【Cloudy】 / 【Fluorescent】 / 【Incandescent】</p>
<p>Color</p>	<p>Set the color effect to add a color tone to the video:</p> <p>【Standard】 / 【Sepia】 / 【Monochrome】 / 【Vivid】</p>
<p>ISO</p>	<p>The ISO menu allows you to set the level of sensitivity that your camera has to light in the surrounding environment.</p> <p>【Auto】 / 【100】 / 【200】 / 【400】</p>
<p>Scene Mode</p>	<p>You can select the scene mode according to the image your wish to capture.</p> <p>【Auto】 / 【Scenery】 / 【Portrait】</p> <p>【Night Scenery】 / 【Night Portrait】</p>

	【High Sensitivity】 / 【Beach】
Anti-shake	Use the function to avoid your hands shaking when taking pictures. 【On】 / 【Off】
Continue Shot	Use this function to take 6 pictures continuously. 【On】 / 【Off】

PLAYBACK MODE

1. Turn on the action camera, press the “Mode” button until

you reach playback mode  .

2. To scroll through the different files, please press and hold “Mode” button and release on the file you want to view.

3. When viewing photos, press the “Shutter/Power” button to bring up the delete menu, use “Mode” button to highlight yes, then press the “Shutter/Power” button confirm and delete the

file.


4. When viewing videos, press the “Shutter/Power” button to bring up the menu which will have Play and Delete, use “Mode” button to highlight, then press the “Shutter/Power” button confirm.

CONNECTION VIA TV

1. Connect the action camera to a TV via the HDMI cable.
2. Turn on the TV and the action camera, and then set the TV HDMI mode.
3. When HDTV is connected, the action camera screen will go black and the TV will display what is shown on your camera. From here you can playback your files on your TV by following the previous steps in playback mode.

USING THE MOUNTING ACCESSORIES

In order to use the action camera more convenient in outdoor sports or in under water situations, we have provided two kinds of main mounts packaged in this camera. Mount **a** is used in fixing to a bike, and mount **b** is used in fixing to a helmet.



a



b



FIXING THE ACTION CAMERA TO A BIKE

1. Find the mount **a**, fix it to the handlebar of a bike by placing the rubber pad, and rotating screws.
2. Choosing connectors from the three given below, and then fix them to the part 1 of the main mount **a**.

3. Fix the connector 2 that have a metal screw on it to the last connector.
4. Fix the tripod slot of the camcorder to the metal screw of the mount 2 respectively.
5. Adjust those screws to make the camcorder more steady and convenient.

FIXING THE ACTION CAMERA TO A HELMET

1. Choose to put the camcorder into the water resistant case or the bracket, then lock it.
2. Fix the connector 3 to the main mount b as given below.



3. Choosing (one, more, none) connector from the three given above, and then fix them to the connector 3.
 4. Fix the connector 2 that have a metal screw on it to the last connector.
 5. Fix the tripod slot of the camcorder to the metal screw of the mount 2 respectively.
 6. Adjust those screws to make the camcorder more steady and convenient.
 7. After fixing the camcorder to the mount correctly, using a strap to fix them to the helmet.
- Insert a strap into the two ends of the main mount **b**, adjust length according to the helmet's size, and then tie the strap up to your helmet.

WATERPROOF CASE CARING INSTRUCTIONS

Before sealing the waterproof case, keep the camera housing's rubber seal clean, a single hair or grain of sand can cause a leak. You can test by closing the case without inserting the camera. Submerge the case completely in water for about a minute. Remove the case from the water, dry off its exterior with a towel, and then open the case. If the entire interior is dry, the case is safe for use under water.

After every use in salt water you will need to rinse the outside of the housing with non-salt water and dry. Not doing this can eventually cause corrosion of the hinge pin and salt build-up in the seal, which can cause corrosion.

To clean the seal, rinse in fresh water and shake dry (drying with a cloth may cause lint to compromise the seal). Re-install the seal into the grooves in the backdoor of the housing.

Please note: the waterproof case is rated for use up to 30 metres deep.

DOWNLOADING FILES TO YOUR COMPUTER

The camera is provided with the plug and play function.


Connect the device to the computer with the USB turn-on camera and then it will be switched into the MSDC mode.

To download image and video files from your digital video camera, connect the camera to your computer. The USB connection on the camera is below the micro SD Slot, connect the USB from here to the PC/Laptop.

1. First time connection the driver will be installed automatically and the below would appear on screen.



2. Once installed the below will be appear.



3. The removable disk icon should be displayed on screen. The following menu will appear on your computer.


Press on "Import pictures and videos."



4. Welcome menu will appear. Press "Next."



5. Select the “Review, organize. And group items to import.”



6. Press on “More options” to select the directory where you want your files saved.



7. Press "OK."
8. Press "Import" to start transfer image to your computer.



9. Your files will now start transferring. When finished, you can review your photos in Windows Live Photo Gallery.

TROUBLESHOOTING

Problem	Solution
I cannot upload images to the PC	Check all cable connections are secured.
	Set the camera to MSDC mode.
I press the shutter button but no response.	Wait for data process to complete and then take your next image. Or Delete some images in SD/MMC card, if the memory is full.
The product does not respond	Press the reset button with a pin, and then turn on the product again.
“Card error”	Format your micro SD card. Then

message appear when Micro SD card is inserted	try again.
	Please use micro SD cards with a class 4 or higher speed to ensure good performance.

NOTE: As a result of continual improvements, the design and specifications of the product within may differ slightly from the unit illustrated on the packaging.