



5 SPEED BLENDER INSTRUCTION MANUAL

MODEL NO.: BBEK1051

IMPORTANT SAFEGUARDS

1. Please read through the following safety precautions carefully before switching on the 5 Speed Blender.
2. Keep this instruction manual in a safe place for future reference. Also keep the sales receipt and, if possible, the gift box with the inner packaging.
3. Failure to follow all the instructions listed may result in electric shock, fire or serious personal injury.
4. Before plugging the 5 Speed Blender into the mains electrical supply, check that the voltage and power supply comply with the specifications indicated on the rating plate of the appliance.
5. Do not plug the appliance into the power supply until it is fully assembled and always unplug before disassembling the appliance or handling the blade.
6. The 5 Speed Blender is not intended for use for by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
7. Always place the 5 Speed Blender on a stable, flat, heat-resistant surface. Also ensure that the surface can take the weight of the unit during use.
8. The 5 Speed Blender is intended for DOMESTIC USE ONLY and should not be used for commercial purposes. The 5 Speed Blender should only be used for its intended purpose.
9. Always keep the 5 Speed Blender out of reach of children. Close adult supervision is necessary when the 5 Speed Blender is used by or near children.
10. Do not leave the unit unattended when not in use.
11. Do not move or lift the 5 Speed Blender while it is operating or while it is connected to an electrical socket.
12. The use of attachments, not specifically recommended by the manufacturer, must not be used as they may cause personal injury or damage to the appliance.
13. Care should be taken when handling the sharp cutting blades, emptying the jug and during cleaning.
14. When mixing hot liquid/food, excess pressure may build up inside the blender and this could cause the lid to come off and the contents to splash out. We therefore recommend that you avoid mixing excessively hot food and that you place very small quantities of hot liquid or food into the blender.
15. Do not use the blender for very hard food products such as bones, shelled nuts, frozen meat etc., which could either damage the blade or cause the motor to seize.
16. The blades of the jug are very sharp. While the blades are turning, never touch the jug from the inside and never place any objects inside the jug.
17. The unit is equipped with a safety function. The unit can only be switched on if the jug is placed on the base properly and locked into position. If the unit cannot be switched on, remove the plug from the mains power supply and check the connection between jug and base. Make sure that the glass jug is properly locked into position before attempting to start operation.
18. Only start operating the unit once the lid is tightly placed onto the glass blending jug and the measuring cup has been inserted into the lid.
19. Do not operate the 5 Speed Blender if the plug or power cord has been damaged, is not working properly, has been dropped or has been exposed to water or other liquid.
20. Check the 5 Speed Blender power cord regularly for damage. If the power cord is damaged in any way, it must be replaced by the manufacturer or its service agent or a similarly qualified person in order to avoid an electrical hazard.
21. Do not allow the power cord to hang over sharp table edges or come into contact with hot surfaces.
22. Make sure that the 5 Speed Blender is switched off and remove the plug from the mains

electrical supply when it is not in use, before it is cleaned, before changing accessories or moving parts and while it is being repaired.

23. Take care when handling the sharp blades, when emptying the glass jug and during the cleaning process.
24. Avoid potential injury through misuse.
25. To prevent the risk of electrical shock, do not immerse the power cord, plug, or any non-removable parts of this 5 Speed Blender in water or any other liquid.
26. The 5 Speed Blender base must not be submerged in water, as any contact with the electrical parts would create the risk of malfunction and electric shock. Do not use the appliance with wet hands.
27. Do not use the 5 Speed Blender outdoors.
28. Always turn the dial to position 'O' to switch OFF the unit before removing the plug from the wall socket.
29. To unplug the appliance, grasp the plug firmly and remove it from the mains electrical supply. **DO NOT PULL ON THE CORD OR CARRY THE UNIT BY ITS CORD.**
30. Never use the 5 Speed Hand Blender if it is damaged in any way.
31. Use only spare parts supplied by the manufacturer or his local dealer.
32. All repairs should be done by a qualified electrician. Improper repairs may place the user at risk.
33. When handing this product over to a third party, ensure that this instruction manual is supplied with the appliance.

TECHNICAL DATA

Power: 220-240V/50/60Hz


Power: 500W

Capacity: 1.5L

Operating time: 2 minute cycles of continuous operation

5 YEAR GUARANTEE

KNOW YOUR 5 SPEED BLENDER



- | | |
|----------------------------------|--------------------|
| 1. Measuring cup | 6. Blade base |
| 2. Blender jug lid | 7. Base unit |
| 3. Glass blender jug | 8. Speed control |
| 4. Blender glass cup base | 9. Power cord |
| 5. Blender glass cup sealed ring | 10. Anti-slip foot |

HOW TO USE YOUR 5 SPEED BLENDER

1. Wash the Measuring Cup, Lid and Glass Blender Jug before first use.
2. Ensure that the 5 Speed Blender is 'OFF' & not connected to the mains electrical supply before assembling.
3. Insert the Glass Blender Jug into the Blade Base and then adjust the Glass Blender Jug so that it is locked into the Blade Base.
4. Place the lid on top of the Glass Blender Jug and press down.
5. Place the Measuring Cup in the centre of the lid and turn it anti-clockwise to lock it into the Lid.

IMPORTANT: Due to the very high speed of the motor, the 5 Speed Blender must be switched off for 1 minute after every 2 minute cycle of continuous operation. The maximum number of cycles per use should be no more than 10 cycles.


THE GLASS BLENDER JUG

IMPORTANT: Never operate the 5 Speed Blender when it is empty or if it is filled with solids only.

1. Always add stock, milk, water or any other liquid specified in the recipe.
2. The Glass Blender Jug has a maximum capacity of 1.5 litres.
3. The high speed rotation of the stainless steel Blades will puree fruit and vegetables, blend batters, dips, sauces and dressings, mix drinks and mayonnaise.
4. It will not beat egg whites, mash potatoes or chop raw meat.
5. The Glass Blender Jug Lid is a 'push fit' and is removed by pulling it off.
6. The small Measuring Cup in the centre of the Glass Blender Jug Lid is for drip feeding oil into the Glass Blender Jug when making mayonnaise.

OPERATION

1. Connect the 5 Speed Blender to the mains electrical supply.
2. Turn the Speed Dial to position '0'.
3. Cut the food to be processed into small pieces and place into the Glass Blender Jug.
4. The cut up food must be covered with liquid. Do not fill liquid above the 1.5L mark.
5. Cover the Glass Blender Jug with the Lid and secure it tightly.
6. Insert the Measuring Cup into lid
7. Switch on the 5 Speed Blender by turning the Speed Control to the speed level required. (P – Pulse; 1 - Lowest speed; 5 - Highest speed)
8. Blending time depends on the type of food as well as the quantity of food used in the recipe.



ENVIRONMENT FRIENDLY DISPOSAL



This marking indicates that this product should not be disposed of with other household waste. To prevent possible harm to the environment or human health from uncontrolled waste disposal, recycle it responsibly to promote the sustainable re-use of material resources. To dispose of your appliance correctly, please contact or take it to your local refuse / recycling centre. Alternatively, contact your local council for information on your local re-use centre. Please make this product environmentally safe for recycling.





5 SPEED BLENDER
MODEL NO : BBEK1051



BRABANTIA CUSTOMER CARE LINE FOR UK ONLY
0844 8540877