

# EXTREME X POWER PACK

## QuickGuide

NIKKEI

### Attention



**Use specified charger only**



**Don't expose to liquids**



**Don't disassemble**



**Avoid Dropping**



**Avoid Extreme temperatures**

### How to use Powerpack



1. Place battery in charger



2. Connect charger to USB-port  
(cable comes with an ExtremeX Action camera)

3. Battery is charged when blue light is on

### The pack contains:

- 3.7 V Li-on battery 900 mAh 3.33Wh
- Micro-USB charger

### Specifications

- Micro-USB 5V connection
- 2 hours charging time
- Charging indicator

The product can be used in combination with all NIKKEI EXTREMEX action cams that have a removable battery.

### Customer Service



[www.nikkei.eu](http://www.nikkei.eu)