

To power on, connect the USB cable to the adapter and product. Plug the adapter to a power socket.

Use batteries as a backup power source. In case of electricity failure this will be used to save the settings.

Battery Installation:
Require 2 AAA Batteries (batteries are not included in accessories)
- Open the battery compartment
- Insert 2 AAA batteries. Observe the polarity.
- Close the battery compartment.

When the product is running on batteries, the following function abilities are limited:

- Time display will be switched off after 5 seconds. Press any key to switch on time display.
- Alarm function is available.
- Radio is available.
- All light functions are unavailable in battery mode.

Setting the Sunset time

Touch ☀️ to switch on/off sunset mode
☀️ symbol appears/disappears on time display
Press and hold 🌅 to set
The hours indication starts to set.
Hours Setting:
Use ⏪⏩ to adjust hours. To confirm press 🌅
Minute setting:
Use ⏪⏩ to adjust minute. To confirm press 🌅



Light

Touch 🌞 to switch on the light
Use ⏪⏩ to adjust the level (1-10) of the brightness
Second touch of 🌞 will switch on automatic color changing mode
Use ⏪⏩ to select color: Green, Red, Blue, Purple, Orange, Indigo
Third touch 🌞 to switch off the light

Sunset light simulation

☀️ 30 min before sunset time, the light is turned on with 100% brightness and then the brightness is reduced gradually and will turn off at sunset time.
During sunset light simulation, if you press and hold 🌞 to turn off the light.

Setting current time

When the power is connected, the hours indication starts to blink.

Hours Setting:
Use ⏪⏩ to adjust hour
To confirm press 🕒


Minute Setting:
Use ⏪⏩ to adjust minute
To confirm press 🕒

If the indication is stopped touch 🕒 again.

12H-24H-format

Press 🕒 key to switch the time format between 12H and 24H

12H
AM or PM will appear on time display.



Changing current time

Touch 🕒 button
The hours indication starts to blink.


Hours Setting:
Use ⏪⏩ to adjust hour
To confirm press 🕒

Minute Setting:
Use ⏪⏩ to adjust minute.
To confirm press 🕒

If the indication is stopped touch 🕒 again.

Intensity of time display

Press 🌞 key to select the display intensity



Description

- * Led time display in 12H-24 format
- * Sunrise wake up light simulation
- * Sunset light simulation
- * 6 Nature sounds to wake up
- * Bedside lamp
- * White light flux: 70LM
- * 10 levels of the brightness
- * 6 colored light + white light
- * Automatic changing of color light
- * FM radio with antenna
- * 15 volume levels
- * Touch mode
- * Power supply: DC 5V; 2xAAA batteries; USB cable.

Note: When the battery is low the product may not function properly.
Replace the cell with fresh cells.



FM Radio

Touch 📻 button to turn on/off. Press and hold 📻 button for 3 seconds to auto scan.

All available FM channels will be scanned and saved automatically.

Touch ⏪⏩ to select an FM station.

Press 🗣️ key to choose volume level 1-15.

Note: time display isn't indicated when Radio is turned on.

Setting the alarm wake-up time

Touch 🕒 button to switch on/off alarm mode.

🕒 symbol appears/disappears on clock display.



Press and hold 🕒 button to set alarm.

The hours indication starts to blink.

Hours Setting:
Use ⏪⏩ to adjust hour.
To confirm press 🕒

Minute Setting:
Use ⏪⏩ to adjust minute.
To confirm press 🕒

If the indication is stopped touch 🕒 again.

Nature sounds



Press 🎵 key to select the alarm sound

Use ⏪⏩ to select 1-7 sounds. Press 🎵 to confirm selection.

Each sound (1-6) will play 5 sec before you choose.

When 7 is selected the last played radio station will be played as wake up sound

Press 🗣️ Key to select volume level 00-15



Sunrise light simulation

When the alarm time is set, the wake up light will switch on 30 minutes before the alarm time in low brightness and gradually increase the brightness. At the alarm time the brightness will be full. The natural sound or radio will be played for 2 minutes at the alarm time.

During wake up alarm play

- Touch 🕒 button to snooze the alarm for 5 minutes. After 5 minutes the alarm will play again for 2 minutes. Press or touch any buttons except 🕒 to stop sound.

- Press and hold 🌞 to switch off wake up light.



- * Don't press two or more keys at the same time
- * To avoid failure interval of every touch must be more than 1 second.
- * If there is any malfunction, please unplug the unit for 3 seconds.
- * If the batteries are not used for a long time, please remove.
- * When the batteries voltage is low, the product will get restarted and all settings are lost. Please replace new batteries.
- * The adapter is designed to use with this product only. Please do not use the adapter to charge other devices like Mobile Phone.

