

Use batteries as a backup power source.In case of electricity failure this will be used to save the settings.

Battery Installation:

Require 3 AAA Batteries(batteries are not included in accessories)

- Open the battery compartment
- Insert 3 AAA batteries. Observe the polarity. Close the battery compartment.

When the product is running on batteries, the are Function abilities limitted:

-Time display will be switched off after 15 seconds. Press any key to switch on time display.

-Alarm function is available.

-Radio is available.

-All light functions are unavailable in battery mode

Setting current time

When the power is connected, the hours indication starts to blink

Hours Setting: Use \bigoplus to adjust hour To confirm press \circledcirc

Minute Setting: Use \bigoplus to adjust minute To confirm press (19)

If the indication is stopped touch ((b) again.

12H-24H-format

Press (12/24) kev to switch the time format between 12H and 24H

Ŋ 12H

AM or PM will appear on time lisplay.



Changing current time

Touch ((1) button The hours indication starts to blink.

Hours Setting: Use \bigcirc to adjust hour To confirm press (1)


Minute Setting: Use \bigcirc to adjust minute.

> If the indication is stopped touch 🕒 again.

Intensity of time display

Press (1) key to select the display intensity





Nature sounds

Press (1) key to select the alarm sound

Use ⊕⊖ to select 1-7 sounds.Press (1) to confirm selection.

Each sound (1-6)will play 5 sec before you choose.

When 7 is selected the last played radio station will be played as wake up sound

Press (Key to select volume level 00-15

 \Diamond

 $\langle \neg$

FM Radio

Touch M button to turn on/off. Press and hold (FM) button for 3 seconds to auto scan.

All available FM channels will be scanned and saved automatically.

Touch $\oplus \ominus$ to select an FM station.

Press (key to choose volume level 1-15.

Note:time display isn't indicated when Radio is turned on.

symbol | appears/disappears on clock display.



Touch (button to switch on/off

alarm mode.

wake-up time

Setting the alarm

Press and hold (button to set alarm.

The hours indication starts to blink.

Hours Setting: Use $\bigoplus \bigcirc$ to adjust hour. To confirm press (A)

Minute Setting:

Use $\bigoplus \bigcirc$ to adjust minute. To confirm press (

If the indication is stopped touch (() again.

Sunrise light simulation

When the alarm time is set, the wake up light will switch on 30 minuts before the alarm time in low brightness and gradually increase the brightness. At the alarm time the brightness will be full. The natural sound or radio will be played for 2 minuts at the alarm time.

During wake up alarm play

- Touch 😰 button to snooze the alarm for 5 minuts. After 5 minuts the alarm will play again for 2 minuts. Press or touch any buttons except (2) to stop sound.

- Press and hold 🔂 to switch off wake up light.



Setting the Sunset time

Touch (to switch on/off

sunset mode on time display

Press and hold (b) to set

The hours indication starts to set. Hours Setting:

Use (+) (-) to adjust hours. To confirm press (&) minute setting:

Use \bigoplus to adjust minute.To confirm press $\textcircled{\textcircled{}}$

Light

Touch to switch on the light
Use to adjust the level (1-10) of the brightness Second touch of (will switch on automatic color

changing mode Use to select color:Green,Red ,Blue,Purple,

Orange,Indigo Third touch (to switch off the light

Sunset light simulation

© 30 min before sunset time, the light is turned on with 100% brightness and then the brightness is reduced gradually and will turn off at sunset time.

uring sunset light is turned on you may: Press and hold to turn off the light.


Description


- *Led time display in 12H-24 format
- *Sunrise wake up light simulation
- *Sunset light simulation
- *6 Nature sounds to wake up
- *Bedside lamp
- *White light flux: 80LM
- *10 levels of the brightness
- *6 coloured light+white light *Automatic changing of color light
- *FM radio with antenna
- *15 volume levels
- *Touch mode
- *Power supply: DC 5V;3xAAA batteries; USB cable.

Note: When the battery is low the product may not function properly.

Replace the cell with fresh cells.









Warning

- * Don't press two or more keys at the same time
- * To avoid failure interval of every touch must be more than 1 second.
- * If there is any malfunction, please unplug the unit for 3 seconds.
- * If the batteries are not used for a long time ,please remove. * When the batteries voltage is low, the product will get restarted and all
- settings are lost . Pls replace new batteries. * The adapter is designed to use with this product only, Please do not use the adapter to charge other devices like Mobile Phone .



